

# WELD ON®

## Proper Applicator Tips



**Use the correct size.** Applicators should be approximately half the pipe diameter.

**To remove excess cement or primer,** use dauber to re-absorb it by lightly grazing the puddled surface.



**For a faster job,** apply the cement over the entire surface area in one motion. Applicators that hold more cement such as the SuperSwab make this task easier.

Visit our website at [www.weldon.com](http://www.weldon.com) for more information or call our tech service line at 1-877-477-8327.



Follow us on Twitter!  
[twitter.com/weldoncements](https://twitter.com/weldoncements)



Like us on Facebook!  
[facebook.com/weldoncements](https://facebook.com/weldoncements)



[www.weldon.com](http://www.weldon.com)