

# WELD ON®

## Cold Weather Tips



**Shake The Can** - cement may freeze in very cold temperatures. Thaw cement by storing indoors at room temperature. Shake vigorously for min. 30 seconds before use.

**Use Premium Primer** - the use of quality primer, such as our P-70, is essential for successful cold weather results.



**Use a Longer Cure Time** - before the system is pressurized. Solvents evaporate slower in colder temperatures.

Visit the full article at [www.weldon.com/pdf/weldon/cold\\_weather.pdf](http://www.weldon.com/pdf/weldon/cold_weather.pdf) for more information or call our tech service line at 1-877-477-8327.



Follow us on Twitter!  
[twitter.com/weldoncements](https://twitter.com/weldoncements)



Like us on Facebook!  
[facebook.com/weldoncements](https://facebook.com/weldoncements)



[www.weldon.com](http://www.weldon.com)