

WELD-ON®

W e t C o n d i t i o n s T i p s

Internal flow in piping system should be completely stopped. Keep pipe as dry as possible and wipe clean before cement application.

Detenga completamente el flujo interno en el sistema de tubería. Mantenga la tubería lo más seca posible y limpie con un trapo antes de la aplicar el cemento.



When dealing with wet conditions, always hold a newly solvent welded pipe and fitting together for longer than the typical duration and a minimum of 30 seconds.

Cuando se trabaje en condiciones húmedas, mantenga juntas la tubería y la conexión recién soldadas por más tiempo de lo normal y con un mínimo de 30 segundos.



Weld-On 725™ Wet 'R Dry, 737™ Turf 'N Ag, and 738™ Hot 'N Fast wet conditions cements are specially formulated with fast acting solvents that evaporate quickly even at low temperatures in wet conditions.

Los cementos Weld-On® 725™ Wet 'R Dry, 737™ Turf 'N Ag, and 738™ Hot 'N Fast están especialmente formulados para condiciones húmedas y con disolventes de pronta acción que se evaporan rápidamente, incluso a bajas temperaturas.



Follow and Like us:



[twitter.com / WeldOnCements](https://twitter.com/WeldOnCements)
[facebook.com / WeldOnCements](https://facebook.com/WeldOnCements)

