

WELD-ON®

Large Diameter Pipe Tips

Achieving leak-free solvent-welded joints is one of the most important things in a piping system installation. This is easily done in large diameter systems by using the right Weld-On® products and following the tips below:

When cutting large diameter pipe, use a pipe wrap or circumferential tape to produce an accurate line to follow when cutting. This will create a pipe-end that is “squarely” cut.

Al cortar tubería de diámetro grande, utilice una abrazadera para tuberías o cinta circumferencial para producir una línea precisa a seguir durante el corte. Esto resultara que el extremo de la tubería sea cortada correctamente.



A swab or roller approximately one-half the size of the pipe diameter should be used for large diameter pipe. Paint or bristle type brushes are not recommended.

Utilice un hisopo o rodillo de aproximadamente la mitad del tamaño del diámetro del tubo para tuberías de diámetro grande. No se recomienda usar cepillos o brochas.

Use a mechanical pipe puller with a center-line attachment that assures proper pipe and fitting alignment during assembly. Do not use heavy equipment like a backhoe as this could easily result in severe damage to the pipe and fittings.

Utilice un tirador para tuberías y conexiones con ajuste central para una alineación apropiada durante el montaje. No utilice equipo pesado como una retroexcavadora ya que esto podría fácilmente ocasionar graves daños a la tubería y conexiones.



Visit www.weldon.com/howtovideo to watch our Solvent Welding Guide for Large Diameter Pipes video.



Follow and Like us:



[twitter.com / WeldOnCements](https://twitter.com/WeldOnCements)
[facebook.com / WeldOnCements](https://facebook.com/WeldOnCements)

