

WELD-ON®

Adhesives Tips

Weld-On 810, 811, and 845 Adhesives should be used as a repair solution, rather than a permanent fix.

Los adhesivos Weld-On 810, 811 y 845 deben utilizarse para reparaciones inmediatas y no como una solución permanente.



For best results, supplement the repair with a piece of thin, flexible, fiberglass mesh in between two layers of adhesive. Only use regular fiberglass mesh with no self-adhesive backing.

Para obtener mejores resultados, complemente la reparación con una pieza delgada y flexible de malla de fibra de vidrio, colocándola entre dos capas de adhesivo. Sólo utilice malla de fibra de vidrio regular, sin autoadhesivo.



Thoroughly clean and dry the target area before applying adhesives. Adhesives should be fully cured before testing or placed into service with wet/humid applications.

Limpié y seque el área a reparar antes de aplicar el adhesivo. Los adhesivos deberán estar completamente curados antes de cualquier prueba o antes de ser usados en aplicaciones húmedas.



Follow and Like us:



[twitter.com / WeldOnCements](https://twitter.com/WeldOnCements)
[facebook.com / WeldOnCements](https://facebook.com/WeldOnCements)

