



# W e t C o n d i t i o n s T i p s

**Internal flow in piping system should be completely stopped. Keep pipe as dry as possible and wipe clean before cement application.**

*Detenga completamente el flujo interno en el sistema de tubería. Mantenga la tubería lo más seca posible y limpie con un trapo antes de la aplicar el cemento.*



**However, Weld-On 725™ Wet 'R Dry, 737™ Turf 'N Ag, and 738™ Hot 'N Fast are specially formulated for wet conditions, with fast acting solvents that evaporate quickly even in low temperatures.**

*Sin embargo, los cementos Weld-On® 725™ Wet 'R Dry, 737™ Turf 'N Ag, and 738™ Hot 'N Fast están especialmente formulados para condiciones húmedas y con disolventes de pronta acción que se evaporan rápidamente, incluso a bajas temperaturas.*

**When dealing with wet conditions, always hold a newly solvent welded pipe and fitting together for longer than the typical duration of 30 seconds.**

*Cuando se trabaje en condiciones húmedas, mantenga la tubería y la conexión recién soldadas juntas por más tiempo de los 30 segundos requeridos.*



Follow and Like us:



[twitter.com / WeldOnCements](https://twitter.com/WeldOnCements)  
[facebook.com / WeldOnCements](https://facebook.com/WeldOnCements)

