

WELD ON®

Hot Weather Tips

By following a few precautions such as the ones below, successful leak-proof joints can be made even in the most extreme hot weather conditions.

Store solvent cements and primers in a cool or shaded area prior to use. Make sure that both pipe and fittings have been sufficiently exposed to the same ambient temperature. Always assemble pipe and fittings in shade, never in direct sunlight.

Almacene los cementos solventes e imprimadores en un lugar fresco y con sombra antes de ser utilizados. Asegúrese de que las tuberías y conexiones estén a la misma temperatura ambiente. Siempre ensamble las tuberías y conexiones en la sombra, nunca bajo la luz solar directa.

Use primer along with a higher viscosity (thicker) cement, which will allow for slightly longer working times.

Utilice imprimador junto con un cemento solvente de mayor viscosidad (más grueso) para permitir más tiempo de trabajo en condiciones de clima caliente.



Work quickly to assemble pipe and fitting immediately after solvent cement is applied and still wet.

Antes de ensamblar, asegúrese de que ambas superficies a unir estén todavía húmedas con cemento solvente.

Visit the full article at www.weldon.com/product-literature/tech-tips for more information or call our tech service line at 1-877-477-8327.



Follow and Like us:



[twitter.com / WeldOnCements](https://twitter.com/WeldOnCements)
[facebook.com / WeldOnCements](https://facebook.com/WeldOnCements)

