

WELD ON®

Hot Weather Tips

Use primer along with a higher viscosity (thicker) solvent cement to allow for more work time in hot weather conditions.

Utilice imprimador junto con un cemento solvente de mayor viscosidad (más grueso) para permitir más tiempo de trabajo en condiciones de clima caliente.



Store solvent cement and primers in cool or shaded area prior to use. Assemble pipe and fittings in the shade whenever possible, and never in direct sunlight.

Almacene el cemento solvente e imprimador en un lugar fresco o con sombra antes de usarse. Siempre que sea posible, ensamble las tuberías y conexiones bajo la sombra y nunca bajo luz solar directa.



Make sure that both surfaces to be joined are still wet with solvent cement before assembling together.

Antes de ensamblar, asegúrese de que ambas superficies a unir estén todavía húmedas con cemento solvente.

Visit the full article at www.weldon.com/pdf/weldon/hot_weather.pdf for more information or call our tech service line at 1-877-477-8327.



Follow and Like us:



[twitter.com / WeldOnCements](https://twitter.com/WeldOnCements)
[facebook.com / WeldOnCements](https://facebook.com/WeldOnCements)

